



Why MRI Machines and MRI-Compatible Medical Devices are Dependent on Non-Magnetic RF Connectors

WHY MRI MACHINES AND MRI-COMPATIBLE MEDICAL DEVICES ARE DEPENDENT ON NON-MAGNETIC RF CONNECTORS

Introductions

The overall benefits of magnetic resonance imaging (MRI) over other imaging techniques have spawned competition and advancement of MRI technologies, as well as new medical devices designed to be compatible with MRI use. While there are established uses for MRI in areas such as neurology, there is a growing use of MRI within the medical community for new applications, such as magnetic resonance angiography (MRA) and cardiac MRI (CMRI) [1]. Hence, there is a growing focus in developing more advanced MRI technology to serve existing applications and enable new use cases.

MRI advancements focus on increasing the resolution of MRI scans and increasing MRI machine magnetic field strength. There is currently research and studies being conducted to develop much higher magnetic field strength MRI machines, which could lead to a transition from the 1.5 to 3 Tesla MRI seen today, to 7 Tesla or even over 10 Tesla MRI [2, 3]. Both of these enhancements hinge on the quality of non-magnetic RF connectors used to carry RF pulses and sense the incredibly weak signals returned by magnetically realigning protons. Greater resolution and higher-power MRI require more, and denser, RF interconnect than previous MRI technologies, creating new design challenges in designing, manufacturing, and maintaining MRI machines.

This article strives to educate MRI manufacturers and industry professionals on the relevant trends with MRI technology and how these trends impact the use of RF interconnect in MRI machines. This article will also touch on the use of non-traditional MRI applications and the growing demand for non-magnetic RF interconnect for implantable medical devices.

MRI/MRA Interconnect Obstacles?

Current MRI machines use many RF connectors, contacts, and cables to send and receive the pulsed RF signals used to image patients. If these connectors, contacts, or coils contain any ferromagnetic material, from impurities or by design, the magnetic field response from the patient can be altered. Any alteration of the signal reduces MRI accuracy. Hence, MRI machines are typically now made with non-magnetic RF interconnect and contacts, which are tested to ensure they yield no magnetic response.

Though using non-magnetic RF connectors and contacts enables higher-resolution MRI, new MRI advances are leading to additional RF interconnect challenges beyond needing merely non-magnetic connectors. To further enhance the resolution and the signal-to-noise ratio (SNR) of an MRI scanner, much higher magnetic field strengths are used [4, 5]. Even with higher-Tesla MRI machines, to take advantage of higher spatial resolution technology, the RF receiver and RF path must introduce as little loss and distortion as possible. Moreover, there are new studies and research on different MRI probe typologies that use an array of magnetic field probes instead of conventional surface coils [6]. These new types of magnetic probe MRI could lead to much higher-resolution MRI but would also require a greater number of RF interconnect and signal processing circuitry.

Resources and References

1. [Will Cardiac MRI Expand?](#)
2. [Magnetic Resonance Imaging \(MRI\) Market - Growth, Trends, and Forecast \(2019 - 2024\)](#)
3. <https://www.nature.com/articles/d41586-018-07182-7>
4. https://www.researchgate.net/publication/281687317_Noninvasive_Electromagnetic_Methods_for_Brain_Monitoring_A_Technical_Review
5. <https://www.ncbi.nlm.nih.gov/pmc/articles/PMC4520483/>
6. <https://www.mtu.edu/news/stories/2018/october/updating-highresolution-mri.html>

WHY MRI MACHINES AND MRI-COMPATIBLE MEDICAL DEVICES ARE DEPENDENT ON NON-MAGNETIC RF CONNECTORS

Denser RF interconnect means that there will likely be a greater need for board-launch, end-launch, and ganged board-to-board RF connectors, in addition to commonly used non-magnetic RF cable assemblies. Given that the majority of suppliers offering RF interconnect have a relatively limited selection of non-magnetic RF solutions compared to standard RF interconnect, MRI manufacturers are often limited in their options for reducing the size and complexity of their MRI design. There may also be nebulous search results if an MRI manufacturer desires high-quality and reliable non-magnetic RF interconnect. This is not the case with Cinch's Johnson RF connectors, which features the broadest portfolio of non-magnetic RF connectors in the industry.

Uses of Non-magnetic RF Interconnect for Medical Applications

There is a trade-off with RF interconnect related to size, frequency, power handling, and insertion loss. Typically, smaller RF connectors are able to channel higher frequencies, but at the cost of lower maximum power handling and increased insertion loss. Special design techniques and materials can be used to mitigate the insertion loss of using smaller RF interconnect and thus enable much smaller RF connections. Though not universally available from every vendor, there is a range of non-magnetic RF connector types used with MRI, mainly N-type, SMA, BNC, SMB, SMC, MCX, MMCX, SMP, SMPM, and 2.92 mm. The type of connector used depends on the frequency, signal power, geometry at the connection point, insertion loss considerations, and installation dynamics.



131-9303-401

131-9711-201

142-9003-201

133-9801-201

133-9303-001

These types of connectors also come in a range of configurations, including end-launch, right-angle, straight, bulkhead, and surface mount receptacles. The connector configuration used in a particular connection depends on the geometric requirements of that connection and how the cable, or board connector, is to be installed. With a greater number of RF probes or magnetic coils in an MRI, more board-mount RF connectors are likely to mitigate the potential footprint increase that additional RF sensors would contribute to the MRI machine. There are relatively limited physical dimensions on the patient housing area and the overall size of an MRI machine, with a need for the superconducting magnet and MRI probes to be as close to the patient as possible. Using much smaller and intelligently configured board-mount non-magnetic RF connectors could enable the development of much more compact MRI machines.

Typical RF connectors are threaded bodies that require precise torque values, and hence torque wrenches, to properly install. There are also snap-on, push-in, or blind-mate style connectors. These types of connectors are designed

WHY MRI MACHINES AND MRI-COMPATIBLE MEDICAL DEVICES ARE DEPENDENT ON NON-MAGNETIC RF CONNECTORS

to make a secure mechanical and electrical connection from merely being pressed together with adequate force. Blind-mate connectors also exhibit resistance to misalignments during mating, and depending on the connector design, may include sophisticated self-aligning features. This is crucial during assembly, installation, and maintenance.

There is also a growing interest in using MRI for more applications, including cardiac imaging and magnetic-resonance angiography (MRA). Though legacy implants with ferromagnetic materials, such as stents or pacemakers, would make using an MRI machine impossible with these patients, there are a growing number of implantable medical devices that are intentionally using non-magnetic components to allow for higher-resolution MRI scans instead of typical CT or SPECT scans. There is also a trend of using wireless connectivity instead of wired connectivity to access, control, and monitor features of implanted medical electronics. For implanted medical devices using wireless technologies to be MRI compatible, they require non-magnetic RF interconnects. As these fields and applications grow, there may be increased use of non-magnetic RF interconnect with implantable medical electronics.

Lastly, using a trusted vendor with a diverse range of non-magnetic RF connectors can also be beneficial during design, production, and throughout the lifetime of an MRI machine[7]. High-quality RF connectors could yield better-performing MRI machines with greater reliability and lower production costs, compared to lower-quality connectors that may have magnetic impurities, suffer from reliability issues, or are difficult to source.

To ensure Cinch's customers receive the highest quality and lowest Mμ connectors possible, Johnson brand of non-magnetic RF interconnect undergo rigorous screening for components and assemblies. This is a substantial added value, as Johnson features the largest variety of non-mag MRI interconnect solutions available.

Uses of Non-magnetic RF Interconnect for Medical Applications

As MRI technologies advance, so too do the requirements of non-magnetic RF connectors essential for carrying the signals used to construct MRI images. Compromises on the quality and design of RF connectors can reduce MRI performance, while leveraging a diverse range of high-quality non-magnetic RF connectors could yield the next generation of high-resolution MRI and MRI-compatible implantable medical devices.

Resources and References

7. [Non Magnetic RF Connectors](#)

ABOUT THE AUTHOR

Ketan Thakkar

Cinch Connectivity Solutions Product Manager for Johnson RF & Microwave product line. He has a Bachelor's Degree in Electrical Engineering from University of Illinois at Urbana-Champaign.

Ketan is a product manager in the electronics / interconnect industry over the past decade. Prior to that, he had a decade of sales and field applications engineering experience in the electronics / semiconductor industry, and a decade of hardware design engineering experience in communications / consumer electronics industry.

Contact Information

☎ +1 630.693.2046

✉ ketan.thakkar@us.cinch.com





About Cinch Connectivity Solutions

For over 100 years, Cinch Connectivity Solutions has manufactured high quality and reliable high-performance connectors and cable assemblies. Cinch is recognized as a world class connectivity supplier of RF, fiber optic, hybrid, microwave components, circular, d-subminiatures, modular rectangular, electronic enclosures and cable assemblies. Cinch provides innovative solutions to the military, commercial aerospace, networking, telecommunication, test and measurement, oil and gas and other harsh environment industries.

We aim to exceed our customers' expectations and continually offer innovative solutions to the rapidly changing needs of the markets and customers we serve.



For more information, please contact us:

North America

+1 507.833.8822

ccsorders@us.cinch.com

Asia-Pacific

+86 21 5442 7668

ccs.asia.sales@as.cinch.com

Europe, Middle East

+44 (0) 1245 342060

CinchConnectivity@eu.cinch.com

belfuse.com/cinch.com

